



Dart Aerospace Ltd.
1270 Aberdeen St
Hawkesbury, ON
K6A 1K7
Canada

Tel (613) 632-5200
Fax 613 632-5246

D3391-023
Job Sheet 193565



Part No: D3391-023

Job Qty: 1 pcs

Part Name: Mid Tube Assembly



Part Weight: 0 lbs

Status: New

Priority: Medium

Job Created: 4/16/19

Job Tracking No:

Due Date: 4/26/19

Created By: Marie Lajeunesse

Type: SOLD

Description: *order 15313*

Note: DWG REV J SHEET 2 and 7 IPP A 05.10.20 New Issue KJ/EC IPP B IPP C 07.03.20 rev F dwg EC IPP D 07.03.28 re-format EC IPP E 07.10.31 ecn 1053P EC IPP Rev:F ECN 1056 07-11-13 DD verified by: EC IPP Rev:G 08-09-08 new process (ecn 08-510) DD verified by:EC IPP Rev:H 08-09-10 revH as per dwg DD verified by:EC IPP Rev: I 08-11-13 Removed steps per w/o, QC KJ verified by: ec IPP Rev:J add in seq 140 expire date &b# sikaflex DD 10.02.17 verified by:EC

Ship Via:

Bill of Materials

Job Routing

Op No	Operation	Qty	Start Date	Due Date	Standard		Workcenter/Supplier		Sign-off
					Setup Hrs	Run Hrs	Workcenter / Supplier	Lead Time	
90	Start up Operation	1 Ea		4/26/19	0.00	0.00	Start Up Skid tubes-1		<i>MBG</i>
100	Skid tubes - 1 - <i>B4B</i>	1 pcs		4/26/19	0.00	2.11	Skid tubes - 1		
							Skid tubes - 2		
							Skid tubes - 3	<i>B4B</i>	<i>MBG</i>
							Skid tubes - 4		
							Skid tubes - 5		
							Skid tubes - 6		
							Skid tubes - 7		
110	QC 5	1		4/26/19	0.00	0.00	QC 5 - 10		
							QC 5 - 12		
							QC 5 - 17		
							QC 5 - 18		
							QC 5 - 19		
							QC 5 - 22		
							QC 5 - 24		
							QC 5 - 3		
							QC 5 - 43		
							QC 5 - 49		
							QC 5 - 51		
							QC 5 - 58		
							QC 5 - 68		
							QC 5 - 9		
							QC 5 - 50		
							QC 5 - 30		
							QC 5 - 40		
120	Handfinish - 1-1 Chemical-B4B	1 pcs		4/26/19	0.00	0.38	Handfinish - 1 - 1 - B4B		
							Handfinish - 1 - 2 - B4B		
							Handfinish - 1 - 3 - B4B		

Plex 4/16/19 1:50 PM Dart.lajeunesse.marie



Container No: S174747



Part: D3391-023

Job No: 193565

Serial No/Batch: S174747

Revision: L

Inspector:

Exp Date:

Instructions: Various STC's

DART Aerospace Ltd.
1270 Aberdeen Street
Hawkesbury, ON K6A 1K7
CANADA
TEL.: 1 613 632-5200
Email: sales@dartaero.com
www.dartaerospace.com

Date: 4/24/19

				Handfinish - 1 - 4 - B4B	
				Handfinish - 1 - 5 - B4B	
				Handfinish - 1 - 6 - B4B	
				Handfinish - 1 - 7 - B4B	<i>24</i>
				Handfinish - 1 - 8 - B4B	
				Handfinish - 1 - 9 - B4B	
				Handfinish - 1 - 10 - B4B	
				Handfinish - 1 - 11 - B4B	
				Handfinish - 1 - 12 - B4B	
				Handfinish - 1 - 13 - B4B	
				Handfinish - 1 - 14 - B4B	
				Handfinish - 1 - 15 - B4B	
				Handfinish - 1 - 16 - B4B	
				Handfinish - 1 - 17 - B4B	
				Handfinish - 1 - 18 - B4B	
				Handfinish - 1 - 19 - B4B	
				Handfinish - 1 - 20 - B4B	
				Handfinish - 1 - 21 - B4B	
				Handfinish - 1 - 22 - B4B	
130	QC 7	1	4/26/19	0.00 0.00	QC 7 - 10
		pcs			QC 7 - 13
					QC 7 - 14
					QC 7 - 15
					QC 7 - 17
					QC 7 - 18
					QC 7 - 19
					QC 7 - 2
					QC 7 - 28
					QC 7 - 3
					QC 7 - 30
					QC 7 - 34
					QC 7 - 36
					QC 7 - 37
					QC 7 - 41
					QC 7 - 47
					QC 7 - 48
					QC 7 - 51
					QC 7 - 58
					QC 7 - 59
					QC 7 - 60
					QC 7 - 9
					QC 7 - 68
					QC 7 - 50
					QC 7 - 67
					QC 7 - 40
140	Skidtubes - 2 - B4B	1	4/26/19	0.00 2.11	Skidtubes - 1 - B4B
		pcs			Skidtubes - 2 - B4B
					Skidtubes - 3 - B4B
					<i>MLG</i>



					Skidtubes - 4 - B4B	
					Skidtubes - 5 - B4B	
					Skidtubes - 6 - B4B	
					Skidtubes - 7 - B4B	
150 QC 5	1 pcs	4/26/19	0.00 0.00		QC 5 - 10	
					QC 5 - 12	
					QC 5 - 17	
					QC 5 - 18	BE
					QC 5 - 19	
					QC 5 - 22	
					QC 5 - 24	
					QC 5 - 3	
					QC 5 - 43	
					QC 5 - 49	
					QC 5 - 51	
					QC 5 - 58	
					QC 5 - 68	
					QC 5 - 9	
					QC 5 - 50	
					QC 5 - 30	
					QC 5 - 40	
160 Skidtubes - 3 - B4B	1 pcs	4/26/19	0.00 2.11		Skidtubes - 1 - B4B	
					Skidtubes - 2 - B4B	
					Skidtubes - 3 - B4B	
					Skidtubes - 4 - B4B	
					Skidtubes - 5 - B4B	BE
					Skidtubes - 6 - B4B	
					Skidtubes - 7 - B4B	
170 QC 10	1 pcs	4/26/19	0.00 0.00		QC 10 - 10	
					QC 10 - 18	
					QC 10 - 24	DAS 24 JUN 05 2019
					QC 10 - 43	9-89
					QC 10 - 50	
					QC 10 - 58	
					QC 10 - 9	
180 QC 5	1 pcs	4/26/19	0.00 0.00		QC 5 - 10	
					QC 5 - 12	
					QC 5 - 17	
					QC 5 - 18	
					QC 5 - 19	
					QC 5 - 22	DAS 24 JUN 05 2019
					QC 5 - 24	9-89
					QC 5 - 3	
					QC 5 - 43	
					QC 5 - 49	
					QC 5 - 51	
					QC 5 - 58	
					QC 5 - 68	
					QC 5 - 9	
					QC 5 - 50	
185 Handfinish - 2-1 Pressure-B4B	1 pcs	4/26/19	0.00 0.00		Handfinish - 2 - 1 - B4B	
					Handfinish - 2 - 2 - B4B	JUN 05 2019
					Handfinish - 2 - 3 - B4B	
					Handfinish - 2 - 4 - B4B	
191 Spray Paint - 2 - B4B	1 pcs	4/26/19	0.00 0.91		Spray Paint - 1 - B4B	1 A2 19-6-6
					Spray Paint - 2 - B4B	
					Spray Paint - 3 - B4B	

				Spray Paint - 4 - B4B	
192 Outsource - 11 - Paint	1	4/26/19		ATE003-VC	W/LA
	pcs				
193 Packaging 2-1 - Receive - B4B	1	4/26/19	0.00 0.00	Packaging 2 - 1 - B4B	W/LA
	pcs			Packaging 2 - 2 - B4B	
				Packaging 2 - 3 - B4B	
				Packaging 2 - 5 - B4B	
				Packaging 2 - 4 - B4B	
				Packaging 2 - 6 - B4B	
				Packaging 2 - 7 - B4B	
				Packaging 2 - 8 - B4B	
				Packaging 2 - 9 - B4B	
				Packaging 2 - 10 - B4B	
				Packaging 2 - 11 - B4B	
				Packaging 2 - 12 - B4B	
				Packaging 2 - 13 - B4B	
				Packaging 2 - 14 - B4B	
				Packaging 2 - 15 - B4B	
				Packaging 2 - 16 - B4B	
				Packaging 2 - 17 - B4B	
				Packaging 2 - 18 - B4B	
				Packaging 2 - 19 - B4B	
				Packaging 2 - 20 - B4B	
				Packaging 2 - 21 - B4B	
				Packaging 2 - 22 - B4B	
				Packaging 2 - 23 - B4B	
				Packaging 2 - 24 - B4B	
				Packaging 2 - 25 - B4B	
				Packaging 2 - 26 - B4B	
				Packaging 2 - 27 - B4B	
				Packaging 2 - 28 - B4B	
				Packaging 2 - 29 - B4B	
				Packaging 2 - 30 - B4B	
				Packaging 2 - 31 - B4B	
				Packaging 2 - 32 - B4B	
				Packaging 2 - 33 - B4B	
				Packaging 2 - 34 - B4B	
				Packaging 2 - 35 - B4B	
				Packaging 2 - 36 - B4B	
200 QC 14	1	4/26/19	0.00 0.00	QC 14 - 15	W/LA 14-6-11
	pcs			QC 14 - 2	
				QC 14 - 34	
				QC 14 - 41	
				QC 14 - 51	
				QC 14 - 58	
				QC 14 - 59	
				QC 14 - 9	
				QC 14 - 68	
				QC 14 - 40	
				QC 14 - 19	
230 Handfinish - 4-1-Assembly-B4B	1	4/26/19	0.00 0.38	Handfinish - 4 - 1 - B4B	W/LA 14-6-11
	pcs			Handfinish - 4 - 10 - B4B	
				Handfinish - 4 - 11 - B4B	
				Handfinish - 4 - 12 - B4B	
				Handfinish - 4 - 13 - B4B	
				Handfinish - 4 - 14 -	

Plex 4/16/19 1:50 PM Dart.lajeunesse.marie

				B4B	
				Handfinish - 4 - 15 - B4B	
				Handfinish - 4 - 2 - B4B	
				Handfinish - 4 - 3 - B4B	
				Handfinish - 4 - 4 - B4B	
				Handfinish - 4 - 5 - B4B	
				Handfinish - 4 - 6 - B4B	
				Handfinish - 4 - 7 - B4B	
				Handfinish - 4 - 8 - B4B	
				Handfinish - 4 - 9 - B4B	
240	QC 5	1	4/26/19	0.00 0.00	QC 5 - 10
		pcs			QC 5 - 12
					QC 5 - 17
					QC 5 - 18
					QC 5 - 19
					QC 5 - 22
					QC 5 - 24
					QC 5 - 3
					QC 5 - 43
					QC 5 - 49
					QC 5 - 51
					QC 5 - 58
					QC 5 - 68
					QC 5 - 9
					QC 5 - 50
					QC 5 - 30
					QC 5 - 40
250	Packaging 3-1 - Stock - B4B	1	4/26/19	0.00 0.00	Packaging 3 - 1 - B4B
		pcs			Packaging 3 - 2 - B4B
					Packaging 3 - 3 - B4B
					Packaging 3 - 4 - B4B
					Packaging 3 - 5 - B4B
					Packaging 3 - 6 - B4B
					Packaging 3 - 7 - B4B
					Packaging 3 - 8 - B4B
					Packaging 3 - 9 - B4B
					Packaging 3 - 10 - B4B
					Packaging 3 - 11 - B4B
					Packaging 3 - 12 - B4B
					Packaging 3 - 13 - B4B
					Packaging 3 - 14 - B4B
					Packaging 3 - 15 - B4B
					Packaging 3 - 16 - B4B
					Packaging 3 - 17 - B4B
					Packaging 3 - 18 - B4B
					Packaging 3 - 19 - B4B
					Packaging 3 - 20 - B4B
					Packaging 3 - 21 - B4B
					Packaging 3 - 22 - B4B
					Packaging 3 - 23 - B4B
					Packaging 3 - 24 - B4B
					Packaging 3 - 25 - B4B
					Packaging 3 - 26 - B4B
					Packaging 3 - 27 - B4B
					Packaging 3 - 28 - B4B
					Packaging 3 - 29 - B4B
					Packaging 3 - 30 - B4B
					Packaging 3 - 31 - B4B

DAS
JUN 10 2019 68
9-89

ML 14-6-17

				Packaging 3 - 32 - B4B	
				Packaging 3 - 33 - B4B	
				Packaging 3 - 34 - B4B	
				Packaging 3 - 35 - B4B	
				Packaging 3 - 36 - B4B	
260 QC 21 - SA	1	4/26/19	0.00 0.00	QC 21 - SA - 21	
	pcs			QC 21 - SA - 70	DAS JUN 17 2019
				QC 21 - SA - 53	21

Part Op 100 - Skid tubes - 1-Cut tube to finish length as per Dwg D3391 2-Drill pilot holes using DT8796 (Do not drill "B" holes) and Descriptions: drill only 1 fwd saddle hole on one side only as per Dwg D3391 3-Open aft saddles and GHW holes to Ø0.4375" except for fwd saddle holes 4-Remove .030" from Fwd indexing Ridge as per Dwg D3391 5-Remove indexing ridge on Fwd & Aft end of skid tube as per Dwg D3391 6-Deburr, scribe batch # on aft end. 7- Locate D3391-021 in D3391-023 at 9.00" (see view F-F) 8- Transfer drill one fwd saddle hole only to .188" dia, transfer drill all remaining fwd saddle holes using DT 8149 locating from previously drill .188" dia hole, using t-pins and clicos to ensure perfect allignment, open up previously tranfer drilled pilot holes in D3391-023/-021 using drill press. ON FIRST SIDE ONLY drill out 2nd and forth fwd saddles holes to 0.500" as per ON 2ND SIDE ONLY ream out 2nd and forth saddle hole to 0.499". D3391-021 BATCH: 5135725 9- Drill #30 pilot holes using wearplate Jig DT8217 Identify Ø0.375" holes with paint marker, ***DO NOT DRILL HOLES #3-19-20 FROM FWD END OF JIG*** Locating from two fwd wearplate holes in D3391-023 drill remaining 6 wearplate holes in D3391-021 using DT8937 10- Open wearplate holes of D3391-023 assembly detail section Q-Q to Ø0.375" (10 holes) as per Dwg D3391 Open wearplate holes of D3391-023 assembly detail section H-H to Ø0.297" (20 holes) as per Dwg D3391 Deburr and blow out all chips from inside

110 - QC5- Inspect part completeness to step on W/O
 120 - Chemical Conversion Coat per QSI005 4.1
 130 - QC7-Inspect Chemical Conversion Coat
 140 - Skid tubes - 1-Open float bag holes as per dwg 2-C'sink float bag holes as per dwg 3- Prepare tube for welding 4- Bond web in place as per Dwg D3391 & QSI 015. Adhere for 12 hours) A/R Sikaflex exp: 19-12-08
 batch#: 5174342 NOTE:ENSURE WEB IS INSERTED IN AFT END OF TUBE
 150 - QC5- Inspect part completeness to step on W/O
 160 - Skid tubes - 1-Weld crossbolt spacer as per dwg D3391 & QSI 004 2-grind weld flush A/R m139011
 170 - QC10- Inspect visual per QSI004- ground welds
 180 - QC5- Inspect part completeness to step on W/O
 185 - Pressure Wash per QSI005 4.3/ Clean and remove all marking - Re-alodine
 191 - Spray Paint / NDT Room - PRIME AS PER DWG AND QSI005 4.2.1.3.3 PRIMER BATCH: 5179552
 PAINT AS PER DWG AND QSI005 4.2.2.4 PAINT: 5183315
 193 - Receive & Inspect for Damage & Mat'l Certs
 200 - QC14- Inspect Spray Paint
 230 - Assemble as per dwg - 1-Install Inserts as per Dwg
 240 - QC5- Inspect part completeness to step on W/O
 250 - Identify as per dwg & Stock Location:
 260 - QC21- Final Inspection - Work Order Release

Job BOM

Part / Item	Component Name	Quantity	Operation	Container
D2500-1-100	Skid tube Extrusion	1 pcs (1 ea)	90-Start up Operation	010 299
D3389-1	Web	1 pcs (1 ea)	140-Skid tubes - 2 - B4B	3163253
D3681-1	Spacer	5 pcs (5 ea)	160-Skid tubes - 3 - B4B	5059800
ALS4-1032-130	Rivnut	20 Ea (20 ea)	230-Handfinish - 4-1-Assembly-B4B	5145873
D3591-1	Bushing	2 pcs (2 ea)	230-Handfinish - 4-1-Assembly-B4B	5057267
				5122431

Job Allocations

Operation	Component Part	Required	Inventory	Allocated
90-Start up Operation	D2500-1-100	1	116	0
140-Skid tubes - 2 - B4B	D3389-1	1	9	0
160-Skid tubes - 3 - B4B	D3681-1	5	156	0
230-Handfinish - 4-1-Assembly-B4B	ALS4-1032-130	20	8,655	0
	D3591-1	2	29	0

Part Specifications

Specifications could not be found.

Plex 4/16/19 1:50 PM Dart.lajeunesse.marie

D3391-041/-043 FLOAT SKIDTUBE ASSEMBLY PARTS LIST

QTY -041	QTY -043	PART NUMBER	DESCRIPTION
X		D3391-041	FLOAT SKIDTUBE ASSEMBLY
	X	D3391-043	FLOAT SKIDTUBE ASSEMBLY
1		D3391-011	FWD TUBE ASSEMBLY
1		D3391-013	MID TUBE ASSEMBLY
1		D3391-015	AFT TUBE ASSEMBLY
	1	D3391-021	FWD TUBE ASSEMBLY
	1	D3391-023	MID TUBE ASSEMBLY
	1	D3391-025	AFT TUBE ASSEMBLY
2	2	D3591-1	BUSHING
4		D3672-3	WASHER
1	1	D4095-041	WEARSHOE
1	1	D4095-043	WEARSHOE
1	1	D4095-045	WEARSHOE
1	1	D4095-047	WEARPAD
1	1	D4095-049	WEARPAD
1	1	D4095-051	WEARSHOE
24	24	AN3C4A	BOLT
4	4	AN3C6A	BOLT
10	10	AN3C7A	BOLT
28	28	NAS1149C0332R	WASHER
10	10	NAS1149C0532R	WASHER
4		MS27038C4-12	SCREW
4		NAS1149C0432R	WASHER

△


SHOP COPY
RETURN TO
ENGINEERING
UNCONTROLLED COPY
SUBJECT TO AMENDMENT


WITHOUT NOTICE
WORK ORDER

NO. 193565MLJ
19-04-16


J	INCORPORATED DSI 9733, REFORMAT DRAWING CHANGED CBORE DEPTH (ZN D2-8, D2-9), REVISED TABLES, REPLACED POWDER COAT WITH PAINT	ML	16.01.14
I	REMOVE GASKETS AND REPLACE ALL WEARSHOES; PARTS LIST UPDATE, ZN A8-1, ZN A8-2, ZN A6-4, ZN B6-8; LPS-3 COATING REMOVED FROM NOTE 2, ZN A3-1, ZN A3-2, REMOVED INSERT AELS-1032-130, ZN B6-4, B2-4, C7-8, C3-8; REMOVED HOLES, ZN D6-4 ZN D2-4, ZN D7-8, ZN D3-8	XDF	11.10.13
H	DRAWING UPDATED TO CURRENT STANDARDS. SHT 1 PL ADDED D3591-1 BUSHING. ZN C8 Ø0.438 DIM WAS 4 PL. ADDED Ø0.499 DIM AND D3591-1 BUSHING. SHT 2 PL ADDED D3591-1 BUSHING. ZN C8 Ø0.438 DIM WAS 4 PL. ADDED Ø0.499 DIM AND D3591-1 BUSHING. (FOR FURTHER INFO SEE DSI 9364 & NCR 08-074)	AJS	08.08.20
G	REPLACE NAS INSERTS W/ AELS INSERTS SWITCH TO D3670-XXXX SPACERS FOR INSTALLING FLOAT BAGS, DWG REORGANIZED FOR CLARITY	DC	07.07.31
F	ADD SS WEARSHOE, GASKET REMOVE FWD SADDLE HOLE -011/-021	PH	07.01.18
E	CHANGE TOLERANCE, EASE MANUFACTURE	PH	06.04.25
D	UPDATE TOLERANCE, CHANGE HOLE SIZE	PH	06.01.23
C	LENGTHEN AFT EXTENSION	PH	05.09.27
B	DRAWING UPDATES	PH	05.06.10
A	NEW ISSUE	PH	05.02.07
REV	DESCRIPTION		BY DATE
DESIGN	PH	DART AEROSPACE USA, INC	
DRAWN	ML	EUGENE, OR	
CHECKED	CP	DRAWING NO.	REV. J
MFG. APPR.		D3391	SHEET 1 OF 11
APPROVED		TITLE	SCALE
DE APPR.		412 FLOAT SKIDTUBE	NTS
DATE	16.01.14		
COPYRIGHT © 2006 BY DART AEROSPACE USA, INC			
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.			

RELEASED
2016-04-28
ECN 16-516







D3391-011 FWD TUBE ASSEMBLY
ASSEMBLY DETAIL



DETAIL A
SCALE 2X



D3391-011 DRILLING DETAIL



D3391-011 BENDING DETAIL
(MAKE FROM D3391-1)

D3391-011 FWD TUBE ASSEMBLY PARTS LIST

QTY	PART NUMBER	DESCRIPTION
X	D3391-011	FWD TUBE ASSEMBLY
1	D3391-1	TUBE
1	D3401-041	TOW CAP
9	D3670-4200	SPACER
4	D3672-1	WASHER
1	D4095-051	WEARSHOE
10	AELS-1032-225	INSERT
10	AN3C4A	BOLT
10	NAS1149C0332R	WASHER

RELEASED
2016-04-28

DESIGN	PH	DART AEROSPACE USA, INC	
DRAWN	ML	EUGENE, OR	
CHECKED	CP	DRAWING NO.	REV.
MFG. APPR.		D3391	SHEET 3 OF 1
APPROVED		TITLE	SCALE
DE APPR.		412 FLOAT SKIDTUBE	NT
DATE	16.01.14	COPYRIGHT © 2005 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL, AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	

INSTALL D3670-4200 SPACER
SEAL WITH MAGNOBOND 6398
GRIND FLUSH
PRIOR TO PAINTING
4 PL

DETAIL B



INSTALL
AELS-1032-225
AFTER FINISH
10 PL

D4095-051
WEARSHOE

AN3C4A BOLT
NAS1149C0332R WASHER
6 PL

D3391-021 FWD TUBE ASSEMBLY ASSEMBLY DETAIL

SEAL WITH
SIKAFLEX-241/-291


D3401-041
TOW CAP

DETAIL B SCALE 2X


AN3C4A BOLT
D3672-1 WASHER
NAS1149C0332R WASHER
4 PL

D3391-021 FWD TUBE ASSEMBLY PARTS LIST

QTY	PART NUMBER	DESCRIPTION
X	D3391-021	FWD TUBE ASSEMBLY
1	D3391-1	TUBE
1	D3401-041	TOW CAP
4	D3670-4200	SPACER
4	D3672-1	WASHER
1	D4095-051	WEARSHOE
10	AELS-1032-225	INSERT
10	AN3C4A	BOLT
10	NAS1149C0332R	WASHER




D3391-021 DRILLING DETAIL




D3391-021 BENDING DETAIL (MAKE FROM D3391-1)

RELEASED
2016-04-28


DESIGN	PH	DART AEROSPACE USA, INC	
DRAWN	ML	EUGENE, OR	
CHECKED	CP	DRAWING NO.	REV.
MFG. APPR.	<i>DS</i>	D3391	SHEET 4 OF 1
APPROVED	<i>BY</i>	TITLE	SCALE
DE APPR.	<i>BY</i>	412 FLOAT SKIDTUBE	NTS
DATE	16.01.14	COPYRIGHT © 2005 BY DART AEROSPACE USA, INC	
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS COVENANT THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.			




D3391-1 TUBE
(MAKE FROM D6013-047 SKIDTUBE MATERIAL)




SECTION C-C



SECTION D-D




SECTION E-E




VIEW F-F
SCALE 2X

RELEASED
2016-04-28

DESIGN	PH	DART AEROSPACE USA, INC	
DRAWN	ML	EUGENE, OR	
CHECKED	CP	DRAWING NO.	REV. J
MFG. APPR.		D3391	SHEET 5 OF 11
APPROVED		TITLE	SCALE
DE APPR.		412 FLOAT SKIDTUBE	NTS
DATE	16.01.14	COPYRIGHT © 2008 BY DART AEROSPACE USA, INC	
THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.			



D3391-013 MID TUBE ASSEMBLY



D3391-013 MID TUBE ASSEMBLY PARTS LIST






QTY	PART NUMBER	DESCRIPTION
X	D3391-013	MID TUBE ASSEMBLY
1	D2500-1-100	EXTRUSION
1	D3389-1	WEB
4	D3672-1	WASHER
4	D3672-3	WASHER
12	D3681-1	SPACER
24	AELS-1032-130	INSERT
4	ALS4-428-165	INSERT
4	MS27039C1-09	SCREW
4	MS27039C4-08	SCREW
4	NAS1149C0332R	WASHER
4	NAS1149C0432R	WASHER

D3391-013 MID TUBE ASSEMBLY

- 1) MATERIAL: MAKE FROM D2500-1-100
- 2) INSTALL D3389-1 WEB TO OUTER TUBE USING SIKAFLEX-241/-291 PER QSI 015
- 3) WELDING: PER DART QSI 004
- 4) USE DART DRILL TEMPLATE DT8217 TO LOCATE AND DRILL Ø0.297 AND Ø0.375 HOLES FOR WEARSHOE INSERTS AND NUTPLATES. CBOR AS NOTED AND INSTALL INSERT/NUTPLATES EXCEPT WHERE INDICATED.

DESIGN	PH	DART AEROSPACE USA, INC	
DRAWN	ML	EUGENE, OR	
CHECKED	CP	DRAWING NO.	REV. J
MFG. APPR.		D3391	SHEET 6 OF 11
APPROVED		TITLE	SCALE
DE APPR.		412 FLOAT SKIDTUBE	NTS
DATE	16.01.14	COPYRIGHT © 2005 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	

RELEASED
2016-04-28



D3391-023 MID TUBE ASSEMBLY PARTS LIST



QTY -023	PART NUMBER	DESCRIPTION
X	D3391-023	MID TUBE ASSEMBLY
1	D2500-1-100	EXTRUSION
1	D3389-1	WEB
5	D3681-1	SPACER
20	AELS-1032-130	INSERT



- D3391-023 MID TUBE ASSEMBLY**
- 1) MATERIAL: MAKE FROM D2500-1-100
 - 2) INSTALL D3389-1 WEB TO OUTER TUBE USING SIKAFLEX-241/-291 PER QSI 015
 - 3) WELDING: PER DART QSI 004
 - 4) USE DART DRILL TEMPLATE DT8217 TO LOCATE AND DRILL Ø0.297 AND Ø0.375 HOLES FOR WEARSHOE INSERTS AND NUTPLATES. CBORE AS NOTED AND INSTALL INSERT/NUTPLATES EXCEPT WHERE INDICATED.

DESIGN	PH	DART AEROSPACE USA, INC	
DRAWN	ML	EUGENE, OR	
CHECKED	CP	DRAWING NO.	REV. J
MFG. APPR.		D3391	SHEET 7 OF 11
APPROVED		TITLE	SCALE
DE APPR.		412 FLOAT SKIDTUBE	NTS
DATE	16.01.14	COPYRIGHT © 2005 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	

RELEASED
2016-04-28



D3391-015 AFT TUBE ASSEMBLY PARTS LIST

QTY	PART NUMBER	DESCRIPTION
X	D3391-015	AFT TUBE ASSEMBLY
1	D2646	AFT CAP
1	D3391-3	AFT TUBE
14	D3670-4200	SPACER
2	D3672-1	WASHER
1	D4095-049	WEARPAD
1	D4095-047	WEARPAD
8	AELS-1032-130	INSERT
4	AELS-1032-225	INSERT
4	ALS4-428-165	INSERT
6	AN3C4A	BOLT
4	AN3C5A	BOLT
20	MS20601AD4	RIVET, BLIND
10	MS21075L5	NUT PLATE, FLOATING
10	NAS1149C0332R	WASHER


NOTES:


- 1) COAT ALL EXPOSED FASTENERS WITH LPS "LPS PROCYON"
- 2) USE DART DRILL TEMPLATE DT8217 TO LOCATE AND DRILL Ø0.297 AND Ø0.375 HOLES FOR WEARSHOE INSERTS AND NUTPLATES. CBORE AS NOTED AND INSTALL INSERT/NUTPLATES EXCEPT WHERE INDICATED.
- 3) ENSURE WALL THICKNESS IS BETWEEN 0.070 AND 0.130 BEFORE INSTALLING INSERT
- 4) ENSURE WALL THICKNESS IS BETWEEN 0.130 AND 0.225 BEFORE INSTALLING INSERT

BENDING AND DRILLING DETAIL

RELEASED
2016-04-28

DESIGN	PH	DART AEROSPACE USA, INC	
DRAWN	ML	EUGENE, OR	
CHECKED	CP	DRAWING NO.	REV. J
MFG. APPR.		D3391	SHEET 8 OF 11
APPROVED		TITLE	SCALE
DE APPR.		412 FLOAT SKIDTUBE	NTS
DATE	16.01.14	COPYRIGHT © 2005 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	






SECTION S-S
SCALE 5X


DRILL Ø0.391
CBORE Ø0.516 X 0.040 DEEP
INSTALL ALS4-428-165 INSERT
4 PL

USE DT8217 DRILL TEMPLATE
TO LOCATE HOLES AND OPEN
TO Ø0.375


MS21075L5 NUTPLATE
REF



SECTION T-T
SCALE 5X
5 PL




DETAIL U
SCALE 5X



DRILLING DETAIL DD
SCALE 10X



1



DETAIL EE
SCALE 2X



DESIGN	PH	DART AEROSPACE USA, INC	
DRAWN	ML	EUGENE, OR	
CHECKED	CP	DRAWING NO.	REV. J
MFG. APPR.		D3391	SHEET 11 OF 11
APPROVED		TITLE	SCALE
DE APPR.		AFT TUBE ASSEMBLY	NTS
DATE	16.01.14	COPYRIGHT © 2005 BY DART AEROSPACE USA, INC THIS DOCUMENT IS PRIVATE AND CONFIDENTIAL AND IS SUPPLIED ON THE EXPRESS CONDITION THAT IT IS NOT TO BE USED FOR ANY PURPOSE OR COPIED OR COMMUNICATED TO ANY OTHER PERSON WITHOUT WRITTEN PERMISSION FROM DART AEROSPACE USA, INC.	

NOTES:
1) USE INDUSTRY STANDARD NUT PLATE DRILL JIG IF REQUIRED.

RELEASED
2016-04-28